

```

1  !pip install segmentation_models

1 import tensorflow as tf
2 import segmentation_models as sm
3 import cv2
4 import os
5 import matplotlib.pyplot as plt
6 import numpy as np
7 from pathlib import Path
8 import yaml
9 import pandas as pd
10 import pickle
11
12 from skimage.filters import *
13
14 from tensorflow.keras.metrics import *
15 from tensorflow.keras.utils import *
16 from tensorflow.keras.applications import *
17 from tensorflow.keras.preprocessing.image import *
18 from tensorflow.keras.models import Sequential, Model
19 from tensorflow.keras.optimizers import Adam
20 from keras.models import load_model
21
22 from sklearn.preprocessing import LabelEncoder
23 from sklearn.linear_model import LinearRegression
24
25 sm.set_framework('tf.keras')
26 sm.framework()

'tf.keras'

```

Double-click (or enter) to edit

```

1 # task parameters
2 SIZE_X = 160
3 SIZE_Y = 224
4 n_classes=3 #Number of classes for segmentation
5
6 # define folder paths for project & data
7 proj_fp = Path(os.getcwd())/"drive/MyDrive/Colab Notebooks/Code Tasks/Biotrillion-Segmentati
8 data_fp = proj_fp/"L2-data"
9 train_data_fp = data_fp/"training_set"
10 test_data_fp = data_fp/"testing_set"
11
12 # Get data index
13 train_data_index = pd.read_csv(train_data_fp/"data_index.csv", index_col='img_id')
14 test_data_index = pd.read_csv(test_data_fp/"data_index.csv", index_col='img_id')
15 #test_data_index.head(2)

1 # Get input and target image data
2 def get_xy_imgs(data_index: pd.DataFrame,
3                 x_col: str, y_col: str):
4     """

```

```

5     get images based on index dataframe
6     parameters
7         data_index (pd.DataFrame): dataframe with file index
8         x_col, y_col (str): name of column for paths of image x and y
9     """
10    img_id = data_index.index
11    x_imgs = [cv2.imread(str(data_index.loc[i][x_col]), 1) for i in img_id]
12    y_imgs = [cv2.imread(str(data_index.loc[i][y_col]), -1) for i in img_id]
13    return np.asarray(x_imgs), np.asarray(y_imgs)
14
15 #Encode labels... but multi dim array so need to flatten, encode and reshape
16 def OHencode_masks(masks: np.array):
17     """
18     One-hot encoding of masks provided as array
19     """
20     labelencoder = LabelEncoder()
21     n, h, w = masks.shape
22     masks_resaped_encoded = labelencoder.fit_transform(masks.reshape(-1,1))
23     masks_encoded_original_shape = masks_resaped_encoded.reshape(n, h, w)
24
25     masks_input = np.expand_dims(masks_encoded_original_shape, axis=3)
26     masks_cat = to_categorical(masks_input, num_classes=n_classes)
27     masks_cat.reshape((n, h, w, n_classes))
28     return masks_cat

```

```


1 # Get train images for standardization
2 train_images, train_masks = get_xy_imgs(train_data_index, x_col="x_img-path", y_col="y_img-p
3 train_masks_input = OHencode_masks(train_masks)
4 X_train, y_train = train_images, train_masks_input
5 # Get test image for testing
6 test_images, test_masks = get_xy_imgs(test_data_index, x_col='x_img-path', y_col='y_img-path
7 test_masks_input = OHencode_masks(test_masks)
8 X_test, y_test = test_images, test_masks_input
9 #print(X_test.shape, y_test.shape)

```

```

/usr/local/lib/python3.7/dist-packages/sklearn/preprocessing/_label.py:115: DataConv
y = column_or_1d(y, warn=True)

```



```

1 # Define loss
2 dice_loss = sm.losses.DiceLoss()
3 focal_loss = sm.losses.CategoricalFocalLoss()
4 total_loss = dice_loss + focal_loss
5
6 # trained models
7 choice = 2
8 mcp_name = ["Unet_transfer-vgg/",
9             "Unet_transfer-FPN/",
10             "U2net_transfer-vgg/"][choice]
11 model_file = [".E159-L0.09.h5", # (not used),
12              ".E23-L0.09.h5", # ,
13              ".E72-L0.09.h5", # ".E105-L0.14.h5"
14              ][choice]
15
16 model_name = mcp_name+ model_file
17 #Set compile=False as we are not loading it for training, only for prediction

```

```

17 #set compile=False as we are not loading it for training, only for prediction.
18 model = load_model(proj_fp/'Models'/model_name,
19                   custom_objects={'f1-score': sm.metrics.FScore(threshold=0.5),
20                                   'total_loss': total_loss},
21                   compile=False)
22 # Load data generator
23 with open(data_fp/"generator"/mcp_name/"test_generator.pkl", "rb") as f: test_datagen = pickl
24
25 #Weighted average ensemble
26 #models = [model1, model2]
27
28 # Make prediction
29 y_pred = model.predict(test_datagen.flow(X_test, y_test, shuffle=False))
30 # Ensemble prediction
31 #preds=np.array([pred1, pred2])
32 #Use tensordot to sum the products of all elements over specified axes.
33 #weighted_preds = np.tensordot(preds, [0.5, 0.5], axes=((0),(0)))

1 def iou(y_true, y_pred, e=1e-9):
2     """
3     compute IOU
4     """
5     def f(y_true, y_pred):
6         intersection = (y_true * y_pred).sum()
7         union = y_true.sum() + y_pred.sum() - intersection
8         x = (intersection + e) / (union + e)
9         return x.astype(np.float32)
10    return tf.numpy_function(f, [y_true, y_pred], tf.float32)
11
12 def get_iou(y_pred:np.array, y_true:np.array,
13            img_id: pd.Index, ch_axis:dict={'pupil':0, 'iris':1}) -> pd.DataFrame:
14     """
15     return iou for predictions as a dataframe
16     parameters:
17         ch_axis: channel axis for each class to be evaluated
18                 # 0 is background, 1: iris, 2: pupil
19     """
20     label = {'pupil':1, 'iris':2}
21     assert len(img_id)== len(y_pred)== len(y_true)
22     iou_ = {k: list() for k in ch_axis.keys()}
23     for i in range(len(img_id)):
24         for name, c in ch_axis.items():
25             iou_[name].append(iou(y_pred[i][:,:,c], y_test[i][:,:,label[name]]))
26     return pd.DataFrame(iou_, index=img_id)
27
28 # Calculate IOU
29 iou_df = get_iou(y_pred, y_test, test_data_index.index,
30                 ch_axis={'pupil':0, 'iris':1})
31 # Save result to csv
32 #iou_df.to_csv(proj_fp/"Results"/("Model-"+model_name.replace('/', '_')+"-iou.csv"))
33 print("\nMean IOU:\n"+str(iou_df.mean()))

```

Mean IOU:

pupil 0.698487


iris 0.788509

dtype: float64

```

1 # Qucik visualization
2 def plot_all_pred(pred_array:np.array, true_array: np.array, ch_axis=dict=[1,2]):
3     """
4     plot all predictions from array (n, h, w, c)
5     """
6     fig, ax = plt.subplots(3, len(pred_array), figsize=(2*len(pred_array),4))
7     for n, p in enumerate(pred_array):
8         ax[0, n].imshow(true_array[n])
9         ax[1, n].imshow(p[:, :, ch_axis[0]])
10        ax[2, n].imshow(p[:, :, ch_axis[1]])
11 plot_all_pred(y_pred, y_test, ch_axis=[0,1])

```



▼ Analysis - Dimater

```

1 # Read data_index csv
2 test_data_index = pd.read_csv(test_data_fp/"data_index.csv").set_index('img_id')
3
4 #test_data_index.head(2)

1 def expand_meta_df(data_index: pd.DataFrame) ->pd.DataFrame:
2     """
3     populate meta info to data index
4     """
5     def get_meta_info(x: pd.Series):
6         """
7         help function: load meta info
8         """
9         with open(x['meta-path']) as f: meta_data = yaml.safe_load(f)
10        x['iris-info'] = meta_data['iris']['ellipse_params']
11        x['pupil-info'] = meta_data['pupil']['ellipse_params']
12        return x
13    data_index = data_index.copy()
14    # get meta info as a column
15    meta_col = data_index.apply(get_meta_info, axis=1)
16    return meta_col
17 # Add meta info to data table
18 test_data_index = expand_meta_df(test_data_index)
19 #test_data_index.head(2)

```

```

1 def blur_filter(im:np.array):
2     """
3     Apply blurring filter and threshold to binary image
4     parameters:
5         im: image (2d, 3d)
6     returns
7         np.array, dtype: uint8
8     """
9     # blur before thresholding
10    blurred_image = gaussian(im, sigma=3)
11    # perform adaptive thresholding to produce a binary image
12    t = threshold_otsu(blurred_image)
13    return (blurred_image > t).astype('uint8')
14
15 def find_contours(im: np.array, plot: bool=False, closing_ks: tuple=(5,5)):
16     """
17     Compute and find contours in masks
18     parameters:
19         im: image (2d, 3d)
20         plot: show plot?
21         clonsing_ks: morphological closing kernel size
22     """
23     # apply filtering
24     im_bin = blur_filter(im)
25     # perform morphological closing to remove noise
26     im_bin = cv2.morphologyEx(im_bin, cv2.MORPH_CLOSE, np.ones(closing_ks, np.uint8))
27     _, pred = cv2.threshold(im_bin, 0, 255, cv2.THRESH_BINARY) # stretch
28     im_color = cv2.cvtColor(pred, cv2.COLOR_GRAY2RGB)
29     # Find full contour tree without chain approximation
30     contours, hierarchy = cv2.findContours(pred, cv2.RETR_TREE, cv2.CHAIN_APPROX_NONE)
31     if plot:
32         plt.imshow(im_bin)
33         cv2.drawContours(im_color, contours, -1, (255,0,0), 1)
34     return contours
35
36 def largest_enclosed_radius(contours:list, im:np.array=None, plot: bool=False):
37     """
38     find largest enclosed radius of objects based on contour object
39     parameters:
40         contour: hierachical contours outputted from cv2.findContours
41         im: image for plotting (optional)
42         bool: show plot? (optional)
43     """
44     cnt = contours
45     radius_best = 224; center_best = (0,0)
46     for i in range (len(cnt)):
47         center, radius = cv2.minEnclosingCircle(cnt[i])
48         if radius <= radius_best:
49             center_best = center
50             radius_best = radius
51     if plot and im is not None:
52         fig, ax = plt.subplots(1)
53         ax.text(10, -10, 'Centre: '+str(center_best), fontsize=11, color = 'red')
54         ax.text(244, -10, 'Diameter: '+str((radius_best*2)/100)+'mm', fontsize=11, color = 'red')
55         ax.imshow(im, cmap='gray')
56         ax.add_artist(plt.Circle(center_best, radius_best ,color='red', fill=False))
57     return center_best, np.round(radius_best,2)

```

```

58
59 def get_eye_info(predictions: np.array, ch_axis: dict={'iris':1, 'pupil':0}):
60     """
61     final function to compute centre and radius of iris & pupil
62     predictions:
63         pred: 3d array (h, w, c)
64         ch_axis: channel axis of image that refers to iris and pupil
65         len(ch_axis) == 2
66     """
67     eye_data = {'iris':[], 'pupil':[]}
68     for name, ch in ch_axis.items():
69         part_data = []
70         for p_im in predictions:
71             contours = find_contours(p_im[:, :, ch])
72             center, radius = largest_enclosed_radius(contours, p_im)
73             part_data.append({'center':center, 'radius': radius})
74         eye_data[name] = pd.DataFrame(part_data)
75     return pd.concat(eye_data, axis=1)
76
77 # Generate prediction tables for predicted diameters metrics for each class
78 pred_eye_info = get_eye_info(y_pred,
79                             ch_axis={'iris':1, 'pupil':0})
80 #pred_eye_info.head(2)

```


```

1 # Test contour finding function
2 im = y_pred[5][:, :, 0]
3 contours = find_contours(im)
4 largest_enclosed_radius(contours, im, plot=True)

```

((114.1603775024414, 80.23584747314453), 10.71)

Centre: (114.1603775024414, 80.23584747314453) Diameter: 0.21425472259521483mm



```

1 def evaluate_agreement(data_df: pd.DataFrame,
2                         pred_df: np.array,
3                         plot: bool = False) -> pd.DataFrame:
4     """
5     compare true iris/pupil radius with predictions
6     paramters:
7         data_df (pd.DataFrame): needs to contain columns 'iris-info' and 'pupil-info'
8         pred_df (pd.DataFrame): needs to contain columns 'iris' and 'pupil'
9     """
10    assert len(data_df) == len(pred_df)
11    data_df = data_df.copy()

```

```

12     pred_df.index = data_df.index
13     # get true radius (long axisZz)
14     iris_radius = data_df.apply(lambda x: x['iris-info']['radius_y'], axis=1)
15     pupil_radius = data_df.apply(lambda x: x['pupil-info']['radius_y'], axis=1)
16     # Compute error, store in dataframe
17     error_df = pd.concat(
18         {'iris-error': (iris_radius-pred_df.iris.radius).abs()/iris_radius*100,
19         'pupil-error': (pupil_radius-pred_df.pupil.radius).abs()/pupil_radius*100
20         }, axis=1)
21     if plot:     # optional linear regress plotting
22         fig, ax = plt.subplots(1)
23         ax.scatter(iris_radius, pred_df.iris.radius); plt.title("iris radius: pred vs true")
24         ax.scatter(pupil_radius, pred_df.pupil.radius); plt.title("pupil radius: pred vs tru
25         ax.text(0.5,0.5, "iris-diam. error:{:.2f}%\npupil-diam. error:{:.2f}%".format(
26             error_df.mean()['iris-error'], error_df.mean()['pupil-error']), transform = ax.t
27         ax.legend(['iris','pupil'])
28     return error_df
29
30 error_df = evaluate_agreement(test_data_index, pred_eye_info, plot=True)
31 # Save results
32 #error_df.to_csv(proj_fp/"Results"/("Model-"+model_name.replace('/', '_')+"-errors.csv"))
33 print("\nMean error%\n"); print(error_df.mean())


```

Mean error%

iris-error 5.871046

pupil-error 9.349446

dtype: float64




```

1  # inspect the images & prediction for more understanding
2  img_id = ['000008491_Ycrop_Hres_R', '000008962_Ycrop_Hres_L', '000009122_Ycrop_Hres_L']
3  def plot_inspect_images_pred(img_id: list, pred_array:np.array, ch_axis=[0,1]):
4      """
5      compare image with
6      """
7      fig, ax = plt.subplots(3, len(img_id))
8      for n, imd in enumerate(img_id):     # plot ground truth images
9          ax[0, n].imshow(plt.imread(test_data_index.loc[imd]['x_img-path']))
10         ax[1, n].imshow(plt.imread(test_data_index.loc[imd]['y_input_img-path']))
11         for r,ch in enumerate(ch_axis): # plot predicted iris & pupil
12             pred_im = pred_array[test_data_index.index.get_loc(imd)]
13             ax[2, n].imshow(np.concatenate([np.expand_dims(pred_im[:, :, 0], axis=2),

```

```
14         pred_im[:, :, :], axis=-1))
15
16 plot_inspect_images_pred(img_id, np.round(y_pred))
```



✓ 0s completed at 11:51 PM

● ✕